



Mitsubishi Diamondpoint NXM76LCD stand disassembly

Written By: Padraic Hoselton





TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Removing the stand.



- Lift the black cover off.
- Remove all 4 Phillips #2 screws.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-12-04 04:52:28 AM.